

How to set up the CCD scanner for use with ComTrac POS

1. Scan the **Program** barcode.



2. Scan the **Preamble** barcode.



3. Scan the preamble barcodes.



Scan first



Scan second

4. Scan the **Finish** barcode.



5. Scan the **End** barcode.



6. Scan the **Program** barcode.



7. Scan the **UPC Setting** barcode.



8. Scan the **Option Code 3** barcode.



9. Scan the **End** barcode.



[OPTIONAL] This will set up the CCD scanner to stay on for 5-6 seconds after the trigger is pressed, or after the scanner scans a good barcode, and will program it to avoid inadvertent double scans.

1. Scan the **Program** barcode.



2. Scan **CCD/Laser Scanner Operation Mode**.



3. Scan the **Option Code 3** barcode.



4. Scan the **End** barcode.



5. Scan the **Program** barcode.



6. Scan the **Auto Power Off Duration** barcode.



7. Scan the **Option Code 2** barcode.



8. Scan the **End** barcode.



9. Scan the **Program** barcode.



10. Scan the **Double Scan Verification** barcode.



11. Scan the **Option Code 3** barcode.



12. Scan the **End** barcode.



If things get completely messed up on your scanner, you can scan the **Master Default** barcode below to reset it.

